



Everything you need from tents to teaspoons

Chafing Dish

We are pleased to provide to you quality equipment for an exceptional dining experience.

Instructions:

1. Fill warming tray with hot water. DO NOT let warming tray run dry as the chafer may become damaged.
2. Ignite sterno, regulate flame as needed.
3. Allow warming tray to pre-heat with cover on before placing food tray in chafer.
4. Please wipe and rinse food surfaces prior to returning. Remove sterno and discard. Place cooled chafer in rental container.

You will be charged a replacement fee for items not returned, or items returned dirty, damaged or broken.

Please call us at 734.354.9591 with any concerns.