



Everything you need from tents to teaspoons

Champagne/Punch Fountain

We are pleased to provide to you quality equipment
for
an exceptional dining experience.

- Do not run fountain without liquid in lower bowl.
- Pre-cool the beverage when possible. Slight overcooling of beverage is recommended.
- To chill a beverage use chunks of ice in the bowl or ice cubes in a plastic bag.
- To empty fountain ladle as much liquid out as possible. Remove rest with a towel.
- Do not immerse base of fountain in water.
- When transporting fountain be careful not to dent or ding sides. Do not rest fountain on its side.

You will be charged a replacement fee for items
returned dirty, broken,
damaged or lost.

Please call us at 734.354.9591 with any concerns.